

	Cure Time, Hr			
	0.5	2	4	8
HMA - Plant	22.8	16.3	15.3	
WMA - Plant		23.5	15.2	13.2
HMA - Lab	23.1	14.2	12.6	
WMA - Lab		74.4	29.3	28.2
	Completed Passes			
HMA - Plant	8620	9265	10000	
WMA - Plant		7658	10000	10000
HMA - Lab	7437	10000	10000	
WMA - Lab		2536	6348	6678
	Air Voids			
HMA - Plant	6.41	6.31	6.46	
WMA - Plant		6.82	6.44	6.44
HMA - Lab	7.46	7.25	7.11	
WMA - Lab		7.03	6.96	7.01

APA / Hamburg - Dry @ 64°C & 10K passes

